
Anchor Winch




- ☐ Manufactured By Doc Freeman's
- ☐ Cast Bronze With A Stainless Steel Shaft
- ☐ Reliable Worm Gear Drive
- ☐ Power Up / Power Down Reversible Motor
- ☐ Lifts Rope Or Chain Anchor Rodes
- ☐ Lifts 60 Feet Per Minute At 350 Pound Pull
- ☐ One Year Limited Warranty On Parts & Labor (Please See Other Side For Warranty Details)

DOC FRO

999 North Northlake Way • Seattle, WA • 98103 800 247-2149 USA 206 633-1500 LOCAL

800 423-8641 WA 206 634-2943 FAX (24 Hour)




Warranty

The McMurry Anchor Winch Is Guaranteed To Be Free Of Defects In Materials And Workmanship Under Normal Use For A Period Of One Year after original consumer purchase. Warranty does not cover removal or re-installation of anchor winch, nor does it cover any incidental or consequential damages that may result from winch failure. Warranty does not cover damage resulting from improper installation, accident, negligence, misuse or from unauthorized alterations. To make a warranty claim, anchor winch must be shipped freight pre-paid to Doc Freeman's, Inc. Proof of purchase is required. The anchor winch will be repaired or replaced at the discretion of

Doc Freeman's, Inc.


Note


Doc Freeman's is not responsible for selection of anchor winch by others, including distributors or agents. All specifications are subject to change without notice and without incurring any obligation to incorporate such changes into products already completed or in the hands of purchasers.



Installation Suggestions

- 1. Mount the winch as close to level as possible to insure proper oil distribution.
- 2. For easier installation and service, install the mounting bolts with the threads and nuts up. This way you can remove the winch without pulling the mounting bolts out of the deck
- 3. Install a positive means of electrically disconnecting the winch from your battery in the event of switch failure.
- 4. A 200 amp fuse or circuit breaker must be used to guard against overload or short circuits.
- IMPORTANT! The McMurry winch uses a dual directional motor. The motor has two electrical connections, one for positive "up" and one for positive "down". The negative (ground) wire connects to the winch's case. See the wiring diagram below.





Service Information

- The oil level is factory filled to the level of the chain break screws (approximately 40 ounces). Do not over fill winch.
- ☐ Use only 140 wt. gear oil in this winch.
- ☐ Motor brushes should be checked once a year. If necessary, replace brushes with Autolite # SB2.
- All parts are available from Doc Freeman's, Inc., the exclusive manufacturer of the McMurry Anchor Winch



